


LuxEOS Flood 9 - Beam 20

LED LUMINAIRES FOR ARCHITECTURAL LIGHTING




Warning

- LuxEOS luminaires must be installed by a qualified electrician.
- Installation must be carried out in accordance with local and/or national electrical installation codes of practice.
- Isolate the mains supply to the driver during installation and whenever subsequently disconnecting or reconnecting the fitting to avoid electric shock.
- Use the correct polarity when wiring, if in any doubt please contact Pulsar.
- Pulsar luminaires are designed for lighting applications and must not be used for any other purpose.
- Unless authorised by Pulsar, field repairs of the luminaire will void the warranty.


MAINS & DATA CONNECTIONS

Typical Connections (Luxeos 9 shown)

LuxCONNECT IP66 Hardwired connection boxes with **separate** Power & DMX wiring & QuickLINK+ luminaire connections



LuxCONNECT IP66 Hardwired connection boxes with **combined** Power & DMX wiring & QuickLINK+ luminaire connections



LuxEOS Flood 9 - Beam 20

LED LUMINAIRES FOR ARCHITECTURAL LIGHTING


CONTROL

LuxEOS luminaires support DMX512, DMX512:1990, (R2013), ANSI E1.20 – 2010 (DMX with RDM V1.0)

All DMX512 protocols are supported including E1.11 DMX with RDM.

Other protocols may be supported with future software releases or hardware add-ons.

DMX Channel order



Start addresses are configured externally via RDM over DMX

RDM

The following RDM Parameter I.D'S (PIDS) are supported


Discovery:	0001 – Discovery_Branch_Unique 0002 – Discovery_Mute 0003 – Discovery_Unmute
Status:	0020 – Queued_Messages 0030 – Status_Messages 0031 – Status_ID_Description
RDM Information:	0050 – Supported_Parameters
Product Information:	0060 – Device_Info 0070 – Product_Detail_ID_List 0080 – Device_Model_Description 0081 – Manufacturer_Label 0082 – Device_Label (Supporting 32 characters of user text) 00C0 – Software_Version_Label
DMX512 Setup:	00E0 – DMX_Personality 00E1 – DMX_Personality_Description 00F0 – DMX_Start_Address 0120 – Slot_Info 0121 – Slot_Description
Sensors:	0200 – Sensor_Definition 0201 – Sensor_Value
Power/Lamp Settings:	0400 – Device_Hours
Control:	1000 – Identify_Device

LuxEOS Flood 9 - Beam 20


LED LUMINAIRES FOR ARCHITECTURAL LIGHTING

MECHANICAL DETAILS (All dimensions in mm)


Front view




Side view



Rear view



Top view



Weights

LuxEOS Flood 9 - 7.2 kgs

LuxEOS Beam 20 - 7.3 kgs

Dimensions


350mm (H) x 255mm (W) x 150mm (D)

LuxEOS Flood 9 - Beam 20


LED LUMINAIRES FOR ARCHITECTURAL LIGHTING

MECHANICAL DETAILS - YOKE BRACKETS

LuxEOS Flood 9 & Beam 40 Yoke Bracket



LuxEOS Flood 18 & Beam 40 Optional Mounting Plate



Hole details

- (A) - Clearance for M12 fixings
 - (B) - Clearance for M10 fixings
 - (C) - M10 Studs for Standard Yoke
- All dimensions in mm

LuxEOS Flood 9 - Beam 20

LED LUMINAIRES FOR ARCHITECTURAL LIGHTING

ADDITIONAL INFORMATION

Mains Supply Cable Colours (Harmonised)

Green/Yellow	Earth - Ground
Brown	Live Phase
Blue	Neutral

DMX Cable Colours (Pulsar)

White	DMX +
Blue	DMX -
Shield	Screen

QuickLINK+ Cable Colours (Power)

Green	Earth - Ground
Black	Live Phase
White	Neutral

QuickLINK+ Cable Colours (Data in)

White	DMX +
Green	DMX -
Shield	Screen

QuickLINK+ Cable Colours (Data through)

Red	DMX +
Blue	DMX -
Shield	Screen

Power Requirements

LuxEOS Flood 9	120 -277V AC @ 50/60Hz	60W	LuxEOS Beam 20	120 -277V AC @ 50/60Hz	45W
----------------	------------------------	-----	----------------	------------------------	-----

Portable Appliance Testing

LuxEOS luminaires may be safely Earth Bond and Insulation tested (500V).

Product Weights

LuxEOS Flood 9	7.2 kgs	LuxEOS Beam 20	7.3 kgs
----------------	---------	----------------	---------

Mechanical Ratings

Ingress Protection IP66

Impact Protection IK09

Maintenance

LuxEOS luminaires should be regularly tested and inspected, and as part of this checked for the build up of external moss and debris which can reduce the light output. If cleaning is required, then a mild water based detergent should be used, care should be taken to avoid the use of harsh solvent based cleaning materials as this could result in damage to the luminaire. Under no circumstances should pressure washers be used for cleaning.

The light source contained in this luminaire shall only be replaced by Pulsar or an authorised service agent or a similar qualified person.

Standards

LuxEOS luminaires conform to the following standards and certification.



UKCA



European CE



RoHS



WEEE

Warranty

Five years from the date of original purchase.

The warranty covers defects in manufacturing workmanship and materials. It is limited to parts and labour.

The warranty becomes void if the product is :-

- A Misused.
- B Not used in accordance with the instructions.
- C The cable connections are not made according to our instructions if the unit is used in damp or wet environments.
- D Repairs are made by unauthorised persons.
- E The serial number label has been removed or defaced.

Pulsar's maximum liability shall not exceed the price paid for the product.

In the unlikely event of a fault occurring, do not use without repair, return the product, with a description of the fault, to your supplier or direct to Pulsar for immediate attention.

Full warranty details are available on request or from our website at www.pulsarlight.com.

As part of our commitment to continuous improvement PULSAR may change the specifications of its products without prior notification or public announcement.

All descriptions, illustrations, drawings and specifications in this publication present only general particulars and shall not form part of any contract.

Please visit our website for the most up to date information.